



How to Pair a Wireless Remote to Your Receiver

Use this guide when programming a new wireless remote or re-syncing a remote after replacing the batteries.



1 BEFORE YOU START



Make sure everything is turned **OFF** and not running, then turn the remote system switch **ON** at the front panel.



You will need access to the receiver box, the handheld remote, and the pairing buttons inside each unit.

2 PAIR THE REMOTE

- 1 Turn the remote system **ON**
- 2 Open the receiver box
- 3 Open the handheld remote
- 4 Locate the receiver pairing button
- 5 Press the receiver button
- 6 Press the handheld remote button
- 7 Listen for the beep
- 8 Confirm pairing

Turn on the switch on the front of the jetter so the receiver has power.

Remove the front panel from the remote-control receiver box.

Remove the back cover from the handheld remote.

Inside the receiver box, find the row of lights and the small button near the center-right of the board.

Press the pairing button inside the receiver box **1** time.

Inside the handheld remote, press the pairing button **2** times.

You should hear **1** beep from the handheld remote.

After the beep, the remote should be programmed.



IMPORTANT:

Press the receiver button first, then press the handheld remote button **2** times.

You should hear **1** beep.

3 TEST THE REMOTE



1. Test all remote functions.



2. Turn the remote system switch **OFF** at the front panel.



3. Turn the remote system switch back **ON**.



4. Test all remote functions again.



5. If the remote does not work after the power-cycle test, contact Jetters Northwest for help.

RECEIVER PAIRING BUTTON



Press the pairing button inside the receiver box **1** time.

HANDHELD REMOTE PAIRING BUTTON



Press this button **2** times.



Need Help? Call **877-901-1936**

Get equipped, and get jetting.